SmoothTalker®

Wideband High Gain Directional Antenna

SEMDA2 Pro Series Log Periodic Directional Antenna



SEMDA2 Pro Series Log Periodic

Weatherproof UV rated inclosure with stainless steel hardware (Parts included as shown below)

Rotational bracket in two planes Screws must be tightened after direction is set










Recommended Installation Guide


- 1. Pole Mount Installation Use Pole Mount Installation Kit shown on page 2. Attach SEMDA2 antenna to the pole* with two stainless steel brackets. Install the pole at the highest possible position. Rotate antenna to find the best signal.
- 2. Outside Wall Installation Choose a wall on the side of the house which shows the best signal on your mobile phone/device. Rotate/Tilt Antenna to obtain the best signal.

Important! In all installations make sure the arrows at the back of antenna housing are pointing up.

* Pole is not included

SEMDA2 Series Antenna Specifications





Beamwidth Vertical: 105 degrees
Beamwidth Horizontal 85 degrees

Dimensions: 295x210x55 mm / 11.6x8.3x2.2 inches

Warranty

This antenna kit is warranted against manufacturing defects for a period of one year from the date of purchase. The original bill of sale is required for any warranty claims. For warranty claim confact original ocaler or **smoothtalker.com**

Pg. 2 WWW.smoothtalker.com Pg. 3